



A RIPLEY® BRAND

MB03-7020 SST DROP SLITTING TOOL Instruction Sheet

Part # MB03-7020


Page 1 of 1

WARNING: THIS TOOL SHOULD NOT BE USED ON LIVE ELECTRICAL CIRCUITS. IT IS NOT PROTECTED AGAINST ELECTRICAL SHOCK!
ALWAYS USE OSHA/ANSI/CE OR OTHER INDUSTRY APPROVED EYE PROTECTION WHEN USING TOOLS. THIS TOOL IS NOT TO BE USED FOR PURPOSES OTHER THAN INTENDED. READ CAREFULLY AND UNDERSTAND INSTRUCTIONS BEFORE USING THIS TOOL.

The SST Drop Slitting Tool will make an error-free, precise separation of the toner wire from Corning SST drop fiber cable. The tool can be used on a mid section of the cable or the cable end. Consult Ripley factory on other brands of toneable flat drop fiber cable.

Seat the cable flat into the tool body with the toner wire toward the blade. Close the handle fully. Slide the tool in either direction to separate the toner wire.

Use the *MILLER*® MB04-7000 FTTX Flat Drop Slitter to then access buffer tubes and fiber.



SST fiber form

Replacement Slitting Blade: CB 209

WARRANTY: RIPLEY warrants its products against defective materials and workmanship for a period of two years from date of shipment from the RIPLEY factory provided the product is utilized in accordance with instructions and specified ratings.



Ripley Tools LLC
46 Nooks Hill Road, Cromwell, CT 06416

P: +1 (800) 528-8665
F: +1 (860) 635-3631

csr@ripley-tools.com
www.ripley-tools.com

Doc. No.	MB03-6001
Approval:	03-22-18